





Smart AC1/TD

Face Recognition Access Device With Fever Detection

Installation Guide


OVERVIEW




Note: Not all products have the function with *, the real product shall prevail.

INSTALLATION ENVIRONMENT


Please refer to the following recommendations for installation.




DEVICE INSTALLATION



- 1 Attach the mounting template sticker to the wall, and drill holes according to the mounting paper. Fix the back plate on the wall using wall mounting screws.




- 2 Attach the device to the back plate.



- 3 Fasten the device to the back plate with a security screw.


STANDALONE INSTALLATION




LOCK RELAY CONNECTION

The system supports Normally Opened Lock and Normally Closed Lock. The NO LOCK (normally opened at power on) is connected with 'NO1' and 'COM' terminals, and the NC LOCK (normally closed at power on) is connected with 'NC1' and 'COM' terminals. Take NC Lock as an example below:


Device not sharing power with the lock




Device sharing power with the lock




RS485 AND RS232 CONNECTION




DOOR SENSOR, EXIT BUTTON & ALARM CONNECTION



WIEGAND READER CONNECTION




POWER CONNECTION



Recommended power supply

- 1) 12V \pm 10%, at least 3000mA.
- 2) To share the power with other devices, use a power supply with higher current ratings.

ETHERNET CONNECTION



Note: In LAN, IP addresses of the server (PC) and the device must be in the same network segment when connecting to software.

timeTec
www.timeteccloud.com